



## 1 INSTRUCTION MANUAL

### KIT BAG 1

 SJK 3x12 12pcs

 SK 4x4 3pcs

 4x10x0.2 12pcs  
(Washer)

 6x12x0.2 6pcs  
(Washer)

 R12100 6 pcs  
(Diff o-ring)

 R11900/1 6 pcs  
8X16X5  
(Bearing)

 R11101 2pcs

 R11146 1pc

 R11103/1 3pcs


 R11104 3pcs

 R11105/1 4pcs

 R11106 2pcs


 R11107 6pcs

 R11108 6pcs


 R11109/1 6pcs

 R11109/2 12pcs

### FRONT/REAR DIFF.




### CENTER DIFF.



## 2 INSTRUCTION MANUAL

### KIT BAG 2


 SiG 3x12 3pcs


 SiG 3x16 2pcs

 SJG 3x20 2pcs

 SK 5x5 1pc


Tcc 3,5x38 2pcs



 15,8x13,2x0,15 1pc  
15,8x13,2x0,3 1pc  
15,8x13,2x0,5 1pc

 R11901/1  
5x16x5 2pcs  
(Bearing)

 R11204/1 1pc

 R11204/2 1pc

 R11300 1pc

 R11303 1pc





 R11304 1pc

 R11125 1pc

 R11114/1 1pc

 R11212/3 1pc

### FRONT GEAR/DIFF. CASE



Hit this side of the diff. to be sure to adjust correctly the washers  
Repeat in step 5 (rear diff.)

## 3 INSTRUCTION MANUAL

### KIT BAG 3

### FRONT UPRIGHT



SK 4x8 2pcs



SK 5x5 2pcs



SN 3 2pcs




R11900/1 4pcs  
8x16x5  
(Bearing)



R11302 4pcs



R11700 4pcs



R11116/2 2pcs




R11501 2pcs




R11500 4pcs




R11116/1 2pcs




R11200R 1pcs R11200L 1pcs



R11201L  
1pc







R11201R  
1pc



R11202/1 2pcs






















R11112 2pcs








Assemble right side  
with the same  
specifications


## 4 INSTRUCTION MANUAL

### KIT BAG 4

-  SiG 3x6 2pcs
-  SiG 3x10 2pcs
-  SiG 3x16 2pcs
-  SK 3x3 2pcs
-  SK 3x5 2pcs
-  SK 3x12 2cs
-  SN 3 4pcs
-  R11201/1 1mm 6pcs
-  R11201/2 2mm 4pcs
-  R11201/3 3mm 2pcs
-  R11201/4 5mm 2pcs
-  R11202/2 1mm 2pcs
-  R11701/1 2pcs
-  R11701/2 2pcs
-  R11701/3 6pcs
-  R11701/4 2pcs
-  R11508 2pcs
-  R11204/3 2pcs
-  R11509 2pcs














-  R11400/1 2pcs (Short)
-  R11400/2 2pcs (Long)
-  R11306 1pc
-  R11510/1 4pcs
-  R11405 1pc












### FRONT ASSEMBLY




## 5 INSTRUCTION MANUAL

### KIT BAG 5

-  SiG 3x6 2pcs
-  SiG 3x8 2pcs
-  SiG 3x12 2pcs
-  SiG 3x14 2pcs
-  SiG 3x16 2pcs
-  SiG 3x18 2pcs
-  SiG 3x20 2pcs
-  SJG 3x20 2pcs
-  SK 5x5 1pc
-  Tcc 3,5x38 2pcs
-  SN 3 4pcs
-  15,8x13,2x0,15 1pc  
15,8x13,2x0,3 1pc  
15,8x13,2x0,5 1pc  
(Washer)
-  R11901/1  
5x16x5 2pcs  
(Bearing)

-  R11204/1 1pc
-  R11204/2 1pc
-  R11212/2 1pc
-  R11212/1 1pc
-  R11206 1pc
-  R11301 1pc
-  R11303 1pc
-  R11305/1 1pc
-  R11305/2 2pcs
-  R1114/1 1pc
-  R11125 1pc

### REAR GEAR / DIFF CASE / WING SUPPORT



## 6 INSTRUCTION MANUAL

### KIT BAG 6

 SG 3x22  
2pcs

 SK 4x8 2pcs


 SK 5x5 2pcs

 SN 3 4pcs

 R11506 2pcs

 R11507 2pcs


 R11900/1  
8x16x5 4pcs  
(Bearing)



 R11207/1 1mm 4pcs  
R11207/2 2mm 4pcs

 R11116/2 2pcs


 R11116/1 2pcs


 R11504 4pcs

 R11404 2pcs






 R11207R 1pc  
 R11207L 1pc

 R11401 2pcs

 R11203 2pcs


 R11112 2pcs


### REAR UPRIGHT




## 7 INSTRUCTION MANUAL

### KIT BAG 7

 SiG 3x6 2pcs

 SiG 3x14 2pcs

 SiG 3x16 2pcs

 SK 3x3 2pcs

 SK 3x5 2pcs

 SK 3x12 2pcs

 SN 3 4pcs

 R11701/1 2pcs


 R11701/2 2pcs

 R11701/3 2pcs

 R11509 2pcs

 R11508 2pcs


 R11204/3 2pcs

 R11400/2 2pcs

 R11510/1 4pcs

 R11406 1pc


### REAR ASSEMBLY






## 8 INSTRUCTION MANUAL

### KIT BAG 8

### STEERING / SERVO SAVER






Adjust toe  
angle -2° as  
original set up









## 9 INSTRUCTION MANUAL

### KIT BAG 9

-  SiG 3x8 2pcs
-  SiG 3x16 1pcs
-  SJG 3x8 2pcs
-  SJG 3x16 1pcs
-  SJG 4x12 2pcs
-  SJG 4X16 2pcs
-  SN 3 2pcs
-  R11507 2pcs



### FRONT / STEERING CHASSIS ASSEMBLY



## 10 INSTRUCTION MANUAL

### KIT BAG 10

 SiG 3x14 1pc

 SJG 3x16 1pc

 SJG 4x12 2pcs


 SJG 4x16 2pcs

 SN 3 1pcs

 R11507 1pc

 R11508 1pc





 R11504 2pcs

 R11308/2 1pc

 R12101 1pc  
o-ring








 R11204/4 1pc

### REAR CHASSIS ASSEMBLY




## 1 1 INSTRUCTION MANUAL

### KIT BAG 11

-  SiG 3x12 4pcs
-  SiG 3x30 4pcs
-  SJG 2,5x6 1pc
-  SJG 3x6 2pcs
-  SJG 3x8 6pcs
-  SJG 4x12 4pcs
-  SK 3x3 2pcs


R11214L 1pc




R11214R 1pc



R11214/1 1pc



R11215 1pc



R11117 4pcs




R11407/3 2pc



R11407/1 1pc



R11407/2 1pc



R11118 2pcs




R11208/1 2pcs



R11208/2 2pcs



R11208/3 2pcs




R11110 1pc














R11111 1pc


### BRAKE / CENTER DIFF MOUNT / STONE GUARDS




## 12 INSTRUCTION MANUAL

### KIT BAG 12

-  SiG 3x6 3pcs
-  SiG 3x8 2pcs
-  SiG 3x10 6pcs
-  SiG 3x14 8pcs
-  SJG 3x8 8pcs
-  Tcc 2,2x9,5 4pcs
-  o-ring 5x3x1 6pcs
-  o-ring 6x2,5x1,8 4pcs
-  SN 3 1pc
-  R11511/2 1pc
-  R11409/2 2pcs



R11210 1pc



R11211/1 1pc



R11211/2 1pc



R11211/3 1pc



R11211/4 4pcs




R11211/5 4pcs




R11511/1 2pcs



R11408 1pc




R11804 1pc







R11311 1pc

### RADIO BOX







## 13 INSTRUCTION MANUAL

### KIT BAG 13













-  SiG 3x14 2pcs
-  SiG 3x6 1pc
-  SJG 3x10 2pcs
-  o-ring 6x2,5x1,8 2pcs

















### FUEL TANK




## 14 INSTRUCTION MANUAL

### KIT BAG 14

-  SiG 3x6 2pcs
-  SJG 4x6 4pcs
-  SJG 4x10 5pcs
-  SG 3x10 4pcs
-  R11902/1 5x10x4 2pcs (Bearing)
-  R12000 5x8x0,1 2pcs
-  R12000 5x8x0,2 2pcs
-  R12000 5x8x0,5 2pcs
-  R11119/1 4pcs
-  SN 4 1pc
-  R11124 1pc
-  R11123 1pc

-  R11805/1 1pc
-  R11120/1 1pc
-  R11120/2 2pcs
-  R11121 2pcs
-  R11122 1pc
-  R11113 1pc
-  R11309 2pcs
-  R11310R 1pc
-  R11310L 1pc
-  Nylon strap 2pcs
-  R11801/1 1pc
-  R11801/2 1pc
-  R11801/3 1pc
-  R11801/4 1pc
-  R11801/5 1pc
-  R11807 1pc Fuel Tube

### ENGINE / AIR FILTER / MUFFLER



## 15 INSTRUCTION MANUAL

### KIT BAG 15



TSb 2,5x8 1pc



TSb 2,5x14 1pc



SK 3x3 3pcs



R11800/5 3pcs



R11800/6 1pc  
Brake (Down)



R11800/7 1pc  
Brake (Up)



R11800/8 1pc  
Conical hole (Gas)



R11800/3 1pcs



R11800/4 1pc






R11800/1 1pc  
Short (Gas)



R11800/2 2pcs  
Long (Brake)


























### GAS / BRAKE LINKAGE





## 16 INSTRUCTION MANUAL

### KIT BAG 16

### FRONT / REAR SHOCKS

-  R11602/2 4pcs
-  R11606/2 4pcs
-  R11607/3 4pcs
-  R11607/2 4pcs
-  R11508 4pcs
-  R11606/4 8pcs (o-ring)
-  R11606/1 4pcs
-  11606/3 4pcs (o-ring)
-  R11611 2pcs (Short)
-  R11613 2pcs (Long)
-  R11615 2pcs (Short)
-  R11616 2pcs (Long)
-  R11612 2pcs (Short)
-  R11604 2pcs (Short)
-  R11614 2pcs (Long)
-  R11605 2pcs (Long)
-  R11609 4pcs
-  R11607/1 4pcs
-  R11603 4pcs
-  R11610 4pcs
-  R11602/3 4pcs
-  R11608 4pcs
-  R11617 4pcs
-  R11602/1 1mm 4pcs
-  R11602/1 2mm 4pcs
-  R11602/1 3mm 4pcs
-  R11602/1 5mm 2pcs
-  R11602/1 8mm 2pcs





## 17 INSTRUCTION MANUAL

KIT BAG 17

SHOCK ASSEMBLY



SJG 3x25 4pcs



SiG 3x20 4pcs







SN 3 4pcs



R11618/1 4pcs



R11618/2 4pcs




## 18 INSTRUCTION MANUAL

KIT BAG 18

BODY / WING / TYRE ASSEMBLY

R11212/4 2pcs





R11409/1 4pcs



R11115 4pcs



R11806 1pc



R11803 1pc

